

NOTES:

- 1. USE ASPHALTIC PATCH (COLD MIX) FOR ASPHALT ROADS THAT IS ON ODOT'S QUALIFIED PRODUCT LIST COMPACT BY VIBRATORY HAMMER.
- PLACE 3/4"-0 AGGREGATE, MEETING OSSC 02630 INTO THE HOLE AND COMPACT WITH A HEAVY, FLAT ENDED RAMMER IN TWO EQUAL LIFTS.
- 3. APPROPRIATE EROSION CONTROL MEASURES FROM THE OREGON STANDARD DRAWINGS SHALL BE USED IF DRILLING OPERATIONS OCCUR NEAR STORMWATER FACILITIES OR STREAMS.
- 4. CORE HOLES SHALL BE SPACED NO CLOSER THAN 25' AND NO MORE THAN FOUR HOLES IN 500' OF A SINGLE LANE.
- 5. IF CORE IS REMOVED FROM PAVEMENT< 5 YRS OLD, CORE HOLE MUST BE REPATCHED WITH NON-SHRINK RAPID-SETTING GROUT.
- 6. THIS DETAIL SHOULD ONLY BE USED FOR THE RESTORATION OF GEOTECHNICAL EXPLORATIONS RELATED TO TRANSPORTATION PROJECTS.

